



If you look through the window the lower arrow is point in when you engage the safety do the trigger and sear disengage? Mean is the sear lifted off the safety? You should be able to see it in the hole when you pull the safety back onto safe.

If it does not but it is not too difficult to engage the safety than I recommend removing a few thousandths of an inch from the flat on the triggers sear as indicated by the top arrow.

Be careful not to change the angle just to remove a couple of thousandths so that the sear and trigger in the hole do not touch when on safe.